



BASALT S3L TRAINER SHOE

PRODUCT CODE: OFW.1017

PRODUCT DESCRIPTION

The Basalt is a lightweight safety trainer that combines water-resistant protection, cushioning, and support with a flexible, durable design for all-day comfort.

FUNDAMENTALS



MIDSOLE
Anti-penetration insole



TOECAP
Plastic toe cap 4522



SOLE
PU/PU-Cod J

CONFORMS TO



EN ISO 20345:2022+A1:2024 S3L FO SR
Issue Date: 15 July 2025

SR
RATED

Slip Resistance (5.3.5.4) Ceramic tile with Sodium Lauryl Sulphate Steel with glycerol

COMPONENTS

UPPER:

U. LEATHER BUFFALO DIN HAIRCELL C/G S- 3

UPPER LINING:

NON-WOVEN PEETAX PE1111

LOWER LINING:

KNITTED FABRICS SPACER 240 GSM

REMOVABLE INSOCK:

LIN KNITTED FABRICS DRYLEX 3 M.M EVA LAMINATION

PENERTRATION-RESISTANT INSERT:

ANTIPERFORATION MORON PROTECTOR - Z

SIZE

Available in sizes:
3-13 (36-48)

WEIGHT

1.30kg

PRODUCT BENEFITS



Water-resistant



Metal free



Anti-static



Cleated grip



Heel energy absorption

SIZE GUIDE

EURO:	34	35	36	37	38	39	41	42	43	44	46	47	48	49	50
UK:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15




THE ULTIMATE GUIDE TO BREAKING
IN AND MAINTAINING YOUR SAFETY
BOOTS

EXPLANATION OF MARKING CODES USED TO DEFINE LEVEL OF PROTECTION PROVIDED

EN ISO 20345:2011 – SB Toe protection tested with 200J impact and 15kN compression force

HRO	Heat resistant outsole compound tested at 300C
P	Penetration resistant outsole tested at 1100N
A	Electrical resistance between foot and ground of between 0.1 and 1000 Mega Ohms
C	Electrical resistance between foot and ground of less than 0.1 Mega Ohms
CI	Insulation against cold
HI	Insulation against heat
E	Energy absorption of the seat region tested at 20 joules
WRU	Water resistant upper leather
I	Insulating footwear
WR	Water resistant footwear
M	Metatarsal protection 100J impact energy
FO	Resistance to fuel oil
SC	Scuff cap with abrasion resistance
WPA	Water penetration and absorption



S RATINGS

In addition, there are the following short codes for commonly used combinations of optional categories of protection:

- SB:** Basic toe protection (200 J)
- S1:** SB + anti-static + energy absorption in heel + closed heel
- S2:** S1 + water penetration/resistance in the upper
- S3:** S2 + penetration-resistant midsole + cleated outsole
- S4/S5:** Like S1/S3 but for fully waterproof polymer/rubber boots (often Wellington-style)

CERTIFICATION BODY

This safety footwear meets the requirements of the safety footwear standard EN ISO 20345:2022+A1 2024 and complies with the European regulation PPE 2016/425 and is certified and assessed by:

A.N.C.I. SERVIZI SRL, operational headquarters CIMAC, via Aguzzafame 60/B, 27029 Vigevano (PV), Italy No0465

Country of origin: INDIA | Commodity code: 6403999390

PRODUCT TECHNOLOGY

Hi-vis flashing for increased visibility: Enhances visibility in low-light or high-risk environments, helping to keep workers safe by making them more noticeable to others. This added safety feature is especially valuable on construction sites, warehouses, or any area with moving machinery or vehicles.

Anti-abrasion scuff cap: The anti-abrasion scuff cap adds an extra layer of durability to high-wear areas, protecting the boot from scuffs, scratches, and surface damage. Designed to withstand tough conditions, it extends the life of the footwear while maintaining a smart, professional appearance.

OFW.1017



THE ULTIMATE GUIDE TO BREAKING IN AND MAINTAINING YOUR SAFETY BOOTS

ROKWEAR[®]


GET IN TOUCH WITH US
 Call: +44 (0) 330 441 3500
 E-mail: uksales@rokwear.com

ANTISTATIC FOOTWEAR

Antistatic footwear should be worn in environments where it's important to reduce the build-up of static electricity—particularly where sparks could ignite flammable materials or vapours. However, it's important to note that antistatic shoes are not designed to protect against electric shock; they only provide limited electrical resistance between the wearer and the ground.

Safety footwear classified as **S1**, **S1P**, or **S3** are always at least antistatic.

This means it helps prevent static electricity from accumulating in your body. Once a certain level of static charge is reached, these shoes safely discharge it into the ground. Antistatic shoes have a resistance between **0.1** and **1000 MegaOhms**, which allows them to safely dissipate electrical energy and reduce the risk of accidental sparks that could ignite fires in hazardous environments with flammable gases, fuels, or solvents.



However, the effectiveness of antistatic footwear can change due to wear and tear, contamination, or moisture. If the footwear becomes wet, especially after long use, it may no longer function properly and could even become conductive. Therefore, it's essential to regularly test the electrical resistance of the footwear, ideally through an in-house testing procedure, to ensure continued protection throughout its life.



WE PROTECT

OFW.1092



OFW.1163



OFW.1018



OFW.1390



OFW.1091



OFW.1089



OFW.1088



SEE THE FULL ROKWEAR SAFETY FOOTWEAR RANGE

ROKWEAR®



THE ULTIMATE GUIDE TO BREAKING IN AND MAINTAINING YOUR SAFETY BOOTS

ROKWEAR®

GET IN TOUCH WITH US
 Call: +44 (0) 330 441 3500
 E-mail: uksales@rokwear.com

BREAKING IN YOUR SAFETY FOOTWEAR

Breaking in new safety boots can be a crucial step in ensuring they fit comfortably and provide adequate protection. Here are some tips to make the process smoother.



Wear them around the house



Gradually increase wear time



Flex & stretch to soften material



Find comfort solutions to problem areas



Don't rush the process

ALLOW A 2 WEEK BREAKING IN PERIOD



REPAIR

If the footwear becomes damaged, it will NOT provide optimum level protection, and therefore should be replaced as soon as possible. Never knowingly wear damaged footwear while carrying risk related activity. If in doubt about the level of damage consult your supplier before using the footwear.



CLEANING

Clean your footwear regularly using high quality cleaning treatments recommended as suitable for the purpose NEVER use caustic or corrosive cleaning agents.



FITTING & SIZING

To put on and take off products, always fully undo the fastening systems. Only wear footwear of a suitable size. Products which are either too loose or too tight will restrict movement and will not provide the optimum level of protection. The sizes of these products are marked on them.



STORAGE AND TRANSPORT

When not in use, store the footwear in a well-ventilated area away from extremes of temperature. Never store the footwear underneath heavy items or in contact with sharp objects. If the footwear is wet, allow it to dry slowly and naturally away from direct heat sources before placing it into storage. Use suitable protective packaging to transport the footwear, e.g. the original container.



COMPATIBILITY

To optimise protection, in some instances it may be necessary to use this footwear with additional PPE such as protective trousers or over gaiters. In this case, before carrying out the risk-related activity, consult your supplier to ensure that all your protective products are compatible and suitable for your application.



WARNING

The footwear must not be worn without hose.



INSOLES

The footwear is supplied with a removable insole which was in place during testing. The insole should remain in place whilst the footwear is in use. It should only be replaced by a comparable insole supplied by the original manufacturer.



WEAR LIFE

The exact life of the product will greatly depend on how and where it is worn and cared for. It is therefore very important that you carefully examine the footwear before use and replace as soon as it appears to be unfit for wear. Careful attention should be paid to the condition of the upper stitching, wear in the outsole tread pattern and the condition of the upper/outsole bond.



THE ULTIMATE GUIDE TO BREAKING IN AND MAINTAINING YOUR SAFETY BOOTS

ROKWEAR[®]

GET IN TOUCH WITH US

Call: +44 (0) 330 441 3500

E-mail: uksales@rokwear.com